





## Note:

- Cavity battens containing copper must be separated from steel cladding by building paper, building wrap, DPC/PVC strips or by painting, otherwise use uPVC Cavibat TM.
- 2. For raking soffits, stop end horizontal sheets at the sloping join.

vcorb\_custom\_orb-soff\_rake

Soffit Line - Vertical VCorb Profile Sloping Sof	fit
Cross Section	

All dimensions in millimetres Scale 1:2 16/01/12