



Note:

1: For raking soffits, stop end horizontal sheets at the sloping join.

vrib_paneldek-soff_hori

Soffit Line - Vertical Rib Profile
Cross Section

All dimensions in millimetres
Scale 1:2
16/01/12