



NOTES:

- 1: Window profile to be selected to achieve cover shown in details.
- 2: Architraves are shown for consistency only, detail may be used with rebated liner.
- 3: Make allowance between packer at sills for support brackets for large windows. Sash support brackets require specific design, and shall be supplied by the window manufacturer.

vrib_trimform-wind_alum_dfx_sill

Framed Window for Vertical Rib Profile
Sill Cross Section

All dimensions in millimetres
Scale 1:2
16/01/12