



Note:

1. Cavity battens containing copper must be separated from steel cladding by building paper, building wrap, DPC/PVC strips or by painting, otherwise use uPVC CavibatTM.
2. For raking soffits, stop end horizontal sheets at the sloping join.

vrib_trimklad-soff_rake

**Soffit Line - Vertical Rib Profile Sloping Soffit
Cross Section**

All dimensions in millimetres
Scale 1:2
16/01/12