





Note:

1: For raking soffits, stop end horizontal sheets at the sloping join.

vcorb_custom_orb-soff_hori

Soffit Line -	Vertical	Corb	Profile
Cross Section			