



**Note:**

1. Cavity battens containing copper must be separated from steel cladding by building paper, building wrap, DPC/PVC strips or by painting, otherwise use uPVC Cavibat™.
2. For raking soffits, stop end horizontal sheets at the sloping joint.

vrib\_st963-soff\_rake

**Soffit Line - Vertical Rib Profile Sloping Soffit  
Cross Section**

All dimensions in millimetres  
Scale 1:2  
03/04/12