


NOTES:

1. Cavity battens containing copper must be separated from steel cladding by building paper, building wrap, DPC, PVC strips or by painting.

vcorb_custom_orb-barg_flush

**Flush Barge For Vertical Corb Profile
Cross Section**


All dimensions in millimetres
Scale 1:2
16/01/12



vcorb_custom_orb-corn_ext

Corner Flashing For Vertical Corb Profile
Cover Flashed External Corner


All dimensions in millimetres
Scale 1:2
16/01/12



vcorb_custom_orb-corn_flash

Corner Flashing for Vertical Corb Profile
For Changes in Cladding Material


All dimensions in millimetres
Scale 1:2
16/01/12



vcorb_custom_orb-corn_int

Internal Corner For Vertical Corb Profile
Cross Section


All dimensions in millimetres
Scale 1:2
16/01/12



vcorb_custom_orb-jctn_clad

Verticalbutt Joint (for Changes In Cladding Material)
Plan


All dimensions in millimetres
Scale 1:2
16/01/12



vcorb_custom_orb-jctn_vert_but

Vertical Butt Joint (for Changes In Cladding Material)
Plan


All dimensions in millimetres
Scale 1:2
16/01/12



vcorb_custom_orb-jctn_wall_floor

Bottom Of Cladding For Vertical Corb Profile
Cross Section

All dimensions in millimetres
Scale 1:2
16/01/12




Note:

1: For raking soffits, stop end horizontal sheets at the sloping join.

vcorb_custom_orb-soff_hori

Soffit Line - Vertical Corb Profile
Cross Section

All dimensions in millimetres
Scale 1:2
16/01/12




Note:

1. Cavity battens containing copper must be separated from steel cladding by building paper, building wrap, DPC/PVC strips or by painting, otherwise use uPVC Cavibat™.
2. For raking soffits, stop end horizontal sheets at the sloping join.

vcorb_custom_orb-soff_rake

Soffit Line - Vertical VCorb Profile Sloping Soffit
Cross Section


All dimensions in millimetres
Scale 1:2
16/01/12



vcorb_custom_orb-wind_alum_flash

Windows For Vertical Corb Profile Window Flashing Layout

All dimensions in millimetres
Scale 1:2
16/01/12




NOTES:

1: Architraves are shown for consistency only, detail may be used with rebated liner.

vcorb_custom_orb-wind_alum_head

Windows For Vertical Corb Profile
Head Cross Section

All dimensions in millimetres
Scale 1:2
16/01/12




NOTES:

- 1: Window profile to be selected to achieve cover shown in details.
- 2: Architraves are shown for consistency only, detail may be used with rebated liner.

vcorb_custom_orb-wind_alum_jamb

**Windows For Vertical Corb Profile
Jamb Cross Section**

All dimensions in millimetres
Scale 1:2
16/01/12



NOTES:

- 1: Window profile to be selected to achieve cover shown in details.
- 2: Architraves are shown for consistency only, detail may be used with rebated liner.
- 3: Make allowance between packer at sills for support brackets for large windows. Sash support brackets require specific design, and shall be supplied by the window manufacturer.

vcorb_custom_orb-wind_alum_sill

Windows For Vertical Corb Profile
Sill Cross Section

All dimensions in millimetres
Scale 1:2
16/01/12